

# Installation Instructions

## 501035 Locking Brass Volleyball Floor Cover Plate by Progressive

### **Please Note: Install Floor Sleeves before installing Floor Plates**

- ① Locate cover plate assembly directly centered over floor sleeve.
- ② Orient the cover so the plate hinges open away from the volleyball court. Mark outer perimeter of cover plate on floor.
- ③ Set router depth to  $\frac{1}{4}$ ".
- ④ Route out floor, staying within the  $7\frac{1}{2}$ " OD circle.
- ⑤ Set cover down in floor in area just routed out. Trim and/or adjust routed area to insure cover plate is flush with top of finished floor.
- ⑥ Re-orient the cover so the plate hinges open away from the volleyball court and drill  $\frac{1}{8}$ " diameter hole  $\frac{1}{4}$ " deep down through all six holes in cover plate.
- ⑦ Install the six #10 x  $1\frac{1}{2}$ " flat head wood screws.
- ⑧ Close cover and lock using screw driver or coin.

